


MODEL : AVS 17

AUDIO/VIDEO UMSCHALTER



Bedienungsanleitung

(Bitte durchlesen vor Inbetriebnahme)


- Produkteigenschaften:**
- Audio/Video Umschalter.
 - Der Audio/Video Umschalter dient zum Anschluss mehrerer A/V Geräte untereinander z.B. Videorecorder, DVD-Player, SAT-Receiver etc.
 - Manueller Umschalter zur Auswahl des A/V Gerätes.
 - Audio/Video Anschlüsse: Cinch-Buchsen.



Anschlüsse und Eigenschaften des Umschalters



Beispiel:



Anmerkungen:

- Zur Vermeidung von Störgeräuschen, schalten Sie die AVS 17 aus. Verbinden Sie die A/V Kabel mit den Cinch-Buchsen.
- Audio/Video nicht im Lieferumfang enthalten.
- Von offenen Flammen fernhalten.

Technische Daten

	Model: AVS 17
Impedanz Eingang/Ausgang	75Ω (Video); 47kΩ (Audio)
Eingangsspegel	1Vp-p (Video); 0.4Vp-p (Audio)
Eingänge	4 Cinch (A/V)
Ausgänge	1 Cinch (A/V)
Abmessungen	200(mm) x 64(mm) x 32(mm)

Problembehebung

Problem	Mögliche Lösung
Kein Bild	1. Überprüfen Sie, ob alle Videokabel mit der richtigen Anschlussbuchse verbunden sind. 2. Überprüfen Sie, ob die Stromschalter der Geräte auf AN stehen.

MODEL : AVS 17


AUDIO/VIDEO SOURCE SELECTOR

OWNER'S MANUAL



(PLEASE READ BEFORE USE)

Product function:


- Home audio/video sources control center.
- Can select different A/V sources connect to TV watch the desired program. Such as VCR, satellite receiver, LD player, DVD, HiFi, etc.
- Manual switch to select input A/V sources.
- Audio/Video ports: RCA jack.



Panel Controls and Features of Universal Type:



Example:



Notes:

- To prevent the noise of the product, please turn it off first, then connect A/V cable to the RCA sockets.
- A/v cable is not included, Please buy it yourself.
- No naked flame sources, such as lighted candles, should be placed on the appliance.

Specifications

Item	AVS 17
Input/Output Impedance	75Ω(Video);47kΩ(Audio)
Input Level	1Vp-p(Video);0. 4Vp-p (Audio)
Input Ports	3RCA(A/V)
Output Ports	1RCA(A/V)
Dimensions	160(mm)× 64 (mm)× 32 (mm)

Trouble shooting Information

Problem	Possible solution
No picture	1.Check to see that all video cables are inserted into the proper connectors. 2.Check power switches on the TV and the video source.(SAT、 DVD、 VCR、 ect.)